

Bullet Edgers







Bullet Edgers

M BENEFITS

- Easy, do-it-yourself installation
- Bullet Edgers help make short work of any landscape project
- Simply dig a shallow trench and lay Bullet Edgers in place
- Bullet Edgers can be installed to create a 51" minimum diameter

M SPECIFICATIONS

- 4" h x 12" w x 4" d (nominal size)
- Weight: 13 lbs.
- 160 Bullet Edgers/pallet

M INSTRUCTIONS

- · Lay Bullet Edgers in your desired pattern. Before digging your base trench, determine how far above grade, if any, you want your units.
- · Excavate your trench to the desired depth. Remove any rocks, roots, or other obstructions, which may cause an unlevel base.
- · A small amount of sand or paver base may be added to your trench to aid in leveling the Bullet Edger units.
- · Place your Bullet Edger units end to end in the prepared trench. Use a rubber mallet to tap the Bullet Edgers firmly into place. Fill and compact along units.
- · Rake, compact, and smooth the surrounding dirt to finish your landscaping project.

Chocolate Granite Grey















Due to inherent characteristics of concrete, color may vary slightly.

No guarantee of color shade is made or implied.



Visit one of our showrooms or learn more at midlandconcreteproducts.com